

## TRX Menus

**To turn on** you press and release. You will hear 3 beeps and the light will be on. You are good to go.

**To turn off**, you press and hold until you hear TADA. Pinpointer and light are off.

There are 3 configure menus.

### **Default configure menu indicator adjust**

1. After the turn off TADA,
2. Hold the button until you get to the configure beep. This is the indicator adjust menu. The TRX will cycle through beep, vibrate or (beep and vibrate).
3. Release the button on the one you want.

*I believe I will only use this menu once. I prefer just the vibrate option and see no reason I will be switching. I prefer to have the sensitivity menu my main menu.*

### **Menu Change**

1. Get into configure mode as explained above.
  2. Release and press the button 3 times and release the last time. You will hear a DA DA TAAAAAA beep. This puts the sensitivity menu first, and the indicators adjust as the 2nd menu.
- This menu will cycle 1, 2, 3, 4 beeps for the 4 sensitivity levels.

### **Audio frequency mode**

There's also a 3rd menu to change frequency.

1. Get into configure mode as explained above.
  2. Release and press the button twice and on the second time, keep holding the button down. - this allows you to select a different audio frequency.
- The actual loudness won't be as loud for the lower frequencies, but if somebody has a hard time hearing the higher frequencies - that might help.

### **Master reset.**

1. Get to configure mode as explained above.
2. Release and press the button 7 times and then it will go back to the factory defaults. Well, mostly. It'll put the indicators and sensitivity and the menu structure back to defaults. If somebody changed their audio, the audio setting will stay as it was set.